





TR-10 – 9-Compartment Glass Rack and Available Extenders

TR-A – Open Extender
 TR-F – Standard Extender
 TR-10 – Glass Rack
 9 Compartments: 6" square



TR-16 – 25-Compartment Glass Rack With Tilt Bar and Available Extenders


TR-A – Open Extender
 TR-B – Standard Extender
 TR-B1 – Dropped Extender
 TR-16 – Glass Rack
 25 Compartments: 3 1/2" square
 Has tilt bar for drainage.



TRAEX® Rack-Master® Full-Size Rack System/Cup Racks

TR-4 – 16-Compartment Cup Rack With Tilt Bar and Available Extenders

TR-A – Open Extender
 TR-D1 – Dropped Extender
 TR-4 – Cup Rack
 16 Compartments: 4 7/16" square.
 Has tilt bar for drainage.



TR-5 – 20-Compartment Cup Rack With Tilt Bar and Available Extenders


TR-A – Open Extender
 TR-5 – Cup Rack
 20 Compartments: 3 1/2" x 4 7/16".
 Has tilt bar for drainage.

Call us at (800) 356-8006.

TRAEX® Rack-Master® Full-Size Rack System/Glass Racks


TR-6 – 25-Compartment Glass Rack and Available Extenders

- TR-A – Open Extender
- TR-B – Standard Extender
- TR-B1 – Dropped Extender
- TR-6 – Glass Rack
25 Compartments: 3 $\frac{1}{2}$ " square




TR-7 – 36-Compartment Glass Rack and Available Extenders

- TR-A – Open Extender
- TR-C – Standard Extender
- TR-C1 – Dropped Extender
- TR-7 – Glass Rack
36 Compartments: 2 $\frac{1}{4}$ " square



TR-8 – 16-Compartment Glass Rack and Available Extenders

- TR-A – Open Extender
- TR-D – Standard Extender
- TR-D1 – Dropped Extender
- TR-8 – Glass Rack
16 Compartments: 4 $\frac{1}{4}$ " square



TR-9 – 49-Compartment Glass Rack and Available Extenders

- TR-A – Open Extender
- TR-E – Standard Extender
- TR-9 – Glass Rack
49 Compartments: 2 $\frac{1}{2}$ " square

